

SRB 1 & 2 Scoreboard Instructions

- Plug in AC adapter and coaxial cable
- Turn on control unit
- Wait for "LOW RAM BATTERY" message to clear
- Enter "1 4 5" for baseball
- Control will ask "Do you want to use wireless" Press "NO"
- Control will ask "Do you want to switch to bright" Press "YES"
- Scoreboard display will light up

To add to any figure simply press the function (Ball, Strike, Out, Inn, Home Score, or Guest Score) and the number of how many you want to add.

EX: For Ball 1 press "Ball" and "1". If next pitch is Ball 2, press "Ball" and "1" again. These scoreboards are "additive".

To reset a number press "Set" (function) (number).

EX: Score is 7 to 2 home leading and guest scores two runs. You accidentally give the runs to home showing 9 to 2 when it should be 7 to 4. Press "Set" "Home Score" "7" and "Set" "Guest Score" "4" to fix.

The "Reset" key clears the ball/strike count.

All balls and strikes will reset any time an out is added that makes it 3 outs.